



KENAY

ORSAY BUTACA /
ORSAY ARMCHAIR

KES-0001ME / KES-0001VE /
KES-0001MO / KES-0001GR /
KES-0001BE



PARTES / PARTS




1 x 1 ud.




2 x 4 uds.

PIEZAS / PIECES



PASO 1 / STEP 1



PRECAUCIÓN / WARNING

Si existe desnivel, añadir pieza A en la pata donde hay dificultades.

If there is incline, add piece F in the leg that has troubles.

